

# Kaymar

## Fitting Instructions



Vehicle LandCruiser 200  
Year  
Type  
Part Reflector Bracket

### Applicable to Part Numbers

K20023L, K20023R, K20026L, K20026R, K20020L, K20020R,  
K20025L, K20025R, K20022L, K20022R,

Date published March 8, 2017

## IMPORTANT - BEFORE COMMENCING INSTALLATION

Please verify the part number corresponds with the list above.

Read through these instructions and check items in the supplied fitting kit matches the attached list.

Every effort is made to ensure instructions are as accurate as possible at the time of publishing however work should not be commenced until the document has been thoroughly read, measurements checked and all components in the package verified as complete. Kaymar has used reasonable care in preparing the information included in these documents, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Kaymar assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Kaymar reserves the right to make changes without further notice to any products to improve reliability, function or design.

### TOYOTA 200 SERIES REFLECTOR BRACKET INSTRUCTIONS

1. Place masking tape on painted surface.
2. Remove carrier arm and pivot corner bracket by removing 4 x M12 x 30 x 1.25 bolts.
3. Fit reflector to bracket using original M6 flange nuts.
4. Fit reflector bracket to main silver corner bracket using 2 x M12 x 30 x 1.25 bolts.

