

Kaymar

Fitting Instructions



Vehicle **Nissan Y62**
Year
Type **Wagon**
Part **Reversing Camera**

Applicable to Part Numbers
K6309-KIT

See also related fitting instructions for reversing sensors, carriers and jerry can holders

Date published November 26, 2019

IMPORTANT - BEFORE COMMENCING INSTALLATION

Please verify the part number corresponds with the list above.

Read through these instructions and check items in the supplied fitting kit matches the attached list.

Every effort is made to ensure instructions are as accurate as possible at the time of publishing however work should not be commenced until the document has been thoroughly read, measurements checked and all components in the package verified as complete.

Kaymar has used reasonable care in preparing the information included in these documents, but makes no representations or warranties as to the completeness or accuracy of the information. Information is supplied upon the condition that the persons receiving the information will make their own determination as to its suitability for their purposes prior to use. Kaymar assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein. Kaymar reserves the right to make changes without further notice to any products to improve reliability, function or design.

Nissan Y62 Reversing Camera Kit

Kaymar

Fitting Instructions



INSTALLATION OF CAMERA

1. Remove rear floor trim by prising up to release clips.



2. Remove the tie down bracket from right hand side lower rear trim. Pull gently to release clips, just enough to get hand in. Do the same to the upper right hand trim.
3. Remove plastic roof trim completely to expose wiring harness.



Kaymar

Fitting Instructions



4. Unplug centre plug and attach to two way camera harness. Run wiring down behind upper and lower trim, cable tie away from any clips to prevent crushing when re-installing trim.



5. Remove small rubber grommet on outside of body. Feed wiring through hole until new grommet comes through and secure grommet in hole.



6. Run camera loom along bottom of carrier arm, and cable tie with cable tie mounts supplied.
7. Bolt black camera bracket to bottom of carrier arm using 2 x M8 x 20 bolts spring and flat washers.
8. Bolt camera to camera bracket, making sure camera is the correct way up.